








# Smart Bulb Color 8W (Bluetooth) - Spesifikasi & Tutorial Pairing

<p><b>Buku Panduan</b></p>  <p>Powered by <b>tuya</b></p> <p>GET IT ON <b>Google Play</b></p> <p>Download on the <b>App Store</b></p> <p>works with <b>Hey Google</b></p> <p>works with <b>Siri Shortcuts</b></p> <p>works with <b>SmartThings</b></p> <p>works with <b>alexa</b></p>	<p>Unduh Aplikasi Rabit Smart &amp; Video Tutorial</p> 	<p><b>Spesifikasi</b></p> <p>Smart Bulb 8W RGBCW Bluetooth</p> <p>Model : Smart Bulb 8W Bluetooth v1 Bluetooth : BLE iBeacon Voltage : 220-240V 50 Hz Braket : e27 Masa Pakai : &gt;20.000 Jam Daya Maksimum : 8W Lumen Maksimum : 800 lm Temperatur Warna : 2700-6500 K Dukungan Sistem : iOS &amp; Android OS</p>	<p>1. Unduh Aplikasi Rabit Smart. 2. Registrasi Akun.</p> 
<p>3. Pastikan Smartphone terkoneksi Bluetooth, lalu tambahkan Perangkat.</p> 	<p>4. Pasang perangkat, untuk reset, nyalakan dan matikan sakelar lampu secara perlahan sebanyak lima kali (nyala-mati-nyala-mati-nyala-mati-nyala-mati-nyala), lampu akan berkedip cepat.</p> 	<p>5. Kontrol Perangkat, dengan tombol yang tersedia dan tombol "edit" untuk pengaturan lebih lanjut. 6. Untuk fungsi otomasi dan penggabungan dengan perangkat Rabit lain. Masuk ke menu "Scene" lalu pilih tombol "+". (Perlu Rabit Bluetooth Gateway)</p> 	 <p><b>rabit</b> #SemakinPintar</p> <p>www.rabit.co.id</p>