








Wall Socket Universal - Spesifikasi & Tutorial Pairing

<h3>Buku Panduan</h3> 	<h3>Unduh Aplikasi Rabit Smart & Video Tutorial</h3> 	<h3>Spesifikasi</h3> <p>Wall Socket - Universal</p> <p>Model : Wall Socket Unversal v1 Tegangan Kerja : AC 110-240 V (50/60Hz) Daya Beban Normal : <80 W Arus Puncak Maksimum : 10 A Daya Puncak Maksimum : 1100 W WiFi : IEEE 802.11 b/g/n 2.4 GHz Dukungan Sistem : iOS & Android OS</p>	<h3>Perakitan</h3> 	<h3>Instalasi</h3> 
<p>1. Unduh Aplikasi Rabit Smart. 2. Registrasi Akun.</p> 	<p>3. Pastikan Smartphone terkoneksi dalam jaringan WiFi, lalu tambahkan Perangkat.</p> 	<p>4. Pasang perangkat, untuk reset, tahan tombol (ON/OFF) pada Wall Socket selama 5 detik. Lampu indikator akan berkedip cepat, dan perangkat siap dipairing.</p> 	<p>5. Kontrol Perangkat, dengan tombol yang tersedia dan tombol "edit" untuk pengaturan lebih lanjut. 6. Untuk fungsi otomasi dan penggabungan dengan perangkat Rabit lain. Masuk ke menu "Scene" lalu pilih tombol "+".</p> 